

WELSTM Sheet Maintenance

CERES WELSTM Sheet features a non-porous, cross linked, reinforced polyurethane wear surface. This surface results in a product that may not require an on-site application of finish depending on the environment, foot traffic, quality of maintenance and the desired gloss level. The following are maintenance instructions based on no on-site finish application.

Safety Precautions

- When performing any wet maintenance, always use wet floor signs and caution tape.
- Refer to each product's MSDS for use of personal protective equipment.



Newly Installed Floor Care

- Keep all foot traffic off the new floor for 12 hours.
- Keep furniture, fixtures and rolling traffic off the new floor for 48 hours.
- Use plywood or other boards when moving heavy objects across the floor.
- Remove all loose debris and adhesive residue with a clean white cloth dampened with mineral spirits. Do not use AFTA.
- Sweep or vacuum to remove any remaining dirt and grit.
- Wait 72 hours (3 days) before wet cleaning the new floor. This will allow the adhesive to fully cure.

Routine Maintenance

- Sweep, dust mop or vacuum to remove all dirt and grit. Do not use treated dust mops.
- Use mop, 175 rpm rotary machine or auto scrubber with red pad and neutral pH cleaner such as Johnson Diversey Stride®. Follow the manufacturer's label instructions.
- Rinse thoroughly with clean water to remove all residue and allow to dry.

Periodic Deep Cleaning

- Sweep, dust mop or vacuum the floor to remove dirt and grit. Do not use treated dust mops.
- Add a stronger neutral pH cleaner such as Johnson Diversey Prominence™ to cool water. Follow manufacturer's instructions.
- Scrub the floor with the cleaning solution using a 175 rpm machine or an auto scrubber. Use a **blue or green pad**. Always wet the pad before use. **Never use a black or a build-up removal pad.**
- Remove the cleaning solution with a wet-dry vacuum or auto scrubber until the floor is dry and free of residue.
- Rinse thoroughly with clean water to remove all residue and allow to dry.

Preventative Floor Care

- Proper matting system is recommended. Mats should be appropriate for soil load and weather conditions. Use mats with a non-staining backing.
- Floor protectors should be used on all furniture legs. The surface area of the floor glide should be no less than 1 inch in diameter.
- Protect the floor from direct sunlight.

Contact Information

For additional information, please call 888-377-8801

Email: ceresinfo@cbcamerica.com

www.cerespvcfreeflooring.com